

Mtn King TPG Field Notes

2024-03-30

- Annual maintenance: emptied, added 1 gal. antifreeze and 1 qt. mineral oil.
- Reset the clock. It was 4 minutes fast.

2018-02-23

- Rebooted the tpg pi, and got data flowing again.
- Downloaded the February csv data from the TPG data logger.
- Wrote cvstochords.py, and submitted the missing TPG data to CHORDS.

2018-02-02

- TPG system stopped connecting to CHORDS; probably due to flakey internet repeater "kitchen".

2018-01-20

- Added 2 qts. mineral to stop the evaporation that has been happening over the last week
- Changed the autosample interval from 15s to 1min.
- Changed tpg.py to use the LAST command rather than the MEAS command. This command doesn't have the time lag of the MEAS command, and perhaps it will save a little on power draw.
- Reset the precip reading to 0.